



On each set screw, just install the screw until it is flush with the inside surface. If there is residual 3D printed gunk from the heat-set installation process, you can clear it by installing the screw backwards first.





Assembled Views


ITEM NO.	DESCRIPTION	QTY.
1	Short Motor Spacer with Insert	1
2	Tall Motor Spacer with Insert	1
3	Y Axis Limit Switch with Harness	1
4	M4 Set Screw, 25mm long	2
5	M3 Buttonhead Screw, 8mm long	1

Spacer Assembly			
60	(i)	Created by:	last edited:
	BY	Joshua Vasquez	5/31/2020
		SCALE: 1:1	SHEET 2 OF 11

В

Make two identical assemblies.

В



Secure both included set screws onto the shaft, ensuring that one set screw engages the flat part of the shaft.


В


The vertical pulley spacing can be dialed in exactly later.

Α

ITEM NO.	DESCRIPTION	QTY.
1	16-T 2GT Drive Pulley for 6mm belt	1
2	Nema17 XY Stepper: LDO-42STH60-2004MAC or 17HM19-2004S	1

Sheet1			
CC BY	Created by: Joshua Vasquez	last edited: 5/31/2020	
	SCALE: 1:1	SHEET 3 OF 11	






Α

ITEM NO.	DESCRIPTION	
1	M3 Standoff, 14mm long, 6mm wide	2
2	M3 Buttonhead Screw, 10mm long	2
3	Machined Left Motor Corner Bracket	1

Left Motor Plate Assembly 1/4			
(cc)	(i)	Created by: Joshua Vasquez	last edited: 5/31/2020
	ву	SCALE: 1:1	SHEET 4 OF 11

В





A

ITEM NO.	DESCRIPTION	
4	M5 Buttonhead Screw, 20mm long	4
5	M5 Drop-In T-Nut for 20x20 Extrusion	4
6	Left Motor Spacer	1


Left Motor Plate Assembly 2/4			
CC	()	Created by: Joshua Vasquez	last edited: 5/31/2020
		SCALE: 1:1	SHEET 5 OF 11

В

These pulleys can be either Gates brand or Generic 2GT, provided that they are between 8.5 and 10mm tall.

В

ITEM NO.	DESCRIPTION	QTY
5	OpenBuilds M5 3mm Spacer	2
6	M5 Shim, 0.2mm thick, 7mm OD	2
7	pulley reinforcement plate for motor	1
8	M4 Shoulder Screw, 16mm-I, 5mm-d	2
9	M3 Buttonhead Screw, 6mm long	2
11	20T toothless idler, 5mm bore	1
12	20T Idler pulley, 2GT, 5mm bore	1




	BY	Joshua Vasquez	5/31/2020
66	(1)	Created by:	last edited:

SCALE: 1:1

SHEET 6 OF 1

В






Α


В

ITEM NO.	DESCRIPTION	
2	M3 Buttonhead Screw, 10mm long	6
11	M3 Washer	4
12	Stepper Motor with Drive Pulley	1

Left Motor Plate Assembly 4/4			
		Created by:	last edited:
Jos		Joshua Vasquez	5/31/2020
		SCALE: 1:1	SHEET 7 OF 11

В





Α

ITEM NO.	DESCRIPTION	
1	Machined Right Motor Corner Bracket	1
2	M3 Standoff, 14mm long, 6mm wide	2
3	M3 Buttonhead Screw, 10mm long	2

Right Motor Plate Assembly 1/4				
<u>@</u>	(i)	Created by: Joshua Vasquez	last edited: 5/31/2020	
		SCALE: 1:1	SHEET 8 OF 11	


В

2

	ITEM NO.	DESCRIPTION	
	3	Tall Motor Corner Plate Spacer Assembly	1
	4	M5 Buttonhead Screw, 30mm long	4
Ī	5	M5 Drop-In T-Nut for 20x20 Extrusion	4

В


Α




2

1

These pulleys can be either Gates brand or Generic 2GT, provided that they are between 8.5 and 10mm tall.



ITEM NO.	DESCRIPTION	
3	20T Idler pulley, 2GT, 5mm bore	1
4	20T toothless idler, 5mm bore	1
5	pulley reinforcement plate for motor	1
6	M3 Buttonhead Screw, 6mm long	2
7	M4 Shoulder Screw, 16mm-l, 5mm-d	2
8	M5 Shim, 0.2mm thick, 7mm OD	2
9	OpenBuilds M5 3mm Spacer	2



Right	Motor	Plate	Assem	bly	3/4

© <u>()</u>	Joshua Vasquez	5/31/2020	
	SCALE: 1:1	SHEET 10 OF 11	

7


1


Α

В

Α







Α

ITEM NO.	DESCRIPTION	
11	M3 Buttonhead Screw, 10mm long	6
12	Stepper Motor with Drive Pulley	1
13	M3 Washer	4
14	20T Idler pulley, 2GT, 5mm bore	1
15	20T Toothless Idler pulley, 2GT, 5mm bore	1

Right Motor Plate Assembly 4/4			
	(i)	Created by:	last edited:
	BY	Joshua Vasquez	5/31/2020
		SCALE: 1:1	SHEET 11 OF 11